

CAMERA AND DISPLAY LENS KIT FOR EL2000SS MODEL K75-37505

INSTRUCTIONS

1. Disconnect power to the unit.
2. Remove the screws (2) holding the microphone plate to the faceplate. Remove the microphone from the faceplate.
3. Disconnect the 16-wire ribbon cable from the display board.
4. Remove the connector at J500 (2 yellow 1 black wires) and pull out the connector from the display board.
5. Remove the screws (6) holding the LCD display assembly.
6. Remove the LCD display assembly and set aside.
7. Remove the standoffs (6) from the LCD display window.
8. Remove the metal backplate from the LCD display window.
9. Remove the display lens from the faceplate and discard. Leave the gasket in place.
10. Remove the standoffs (3) from the camera window.
11. Remove the metal backplate from the camera window.
12. Remove the camera lens from the faceplate and discard.
13. Remove and discard the entire gasket and clean the surface to remove any debris.
14. Position the new gasket onto the faceplate.
15. Remove the white protective film from both lenses. Position the lenses onto faceplate with the brown side facing the inside of the enclosure.
16. Remove the brown protective film from the back of the lenses, then reverse the above steps to re-assemble.

NOTE: Make sure that the moon-shaped notch in the camera window backplate aligns with the microphone hole in the camera lens.

Tighten standoffs snugly using your hands. If you prefer to use a tool, be careful not to overtighten and damage the gasket.

LCD Lens Orientation -IMPORTANT		
Lens side	Protective film	Note
Antiglare side	white film	After peeling the protective film, this side faces the outside of the unit and is mounted against the gasket.
Internal facing side	brown film	This faces the inside of the unit, and is mounted against the back plate.

⚠ WARNING

To prevent possible **SERIOUS INJURY** or **DEATH** from electrocution, disconnect electric power to unit **BEFORE** installing.
ALL electrical connections **MUST** be made by a qualified individual.

