


# Logic 4.0 for Models J, H, HJ

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



# Logic 4.0 for Models J, H, HJ

## REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<a href="#">K13-10024</a>	LIMIT NUT
2	<a href="#">K23-10041</a>	LIMIT SWITCH, SPDT, 10A, 125/250VAC
3	<a href="#">K75-35626</a>	E-BOX, COVER, J, H, HJ
4	<a href="#">K21-14182</a>	TRANSFORMER, 120/240V, 24VAC, 20VA
	<a href="#">K21-35057</a>	TRANSFORMER, 460V, 24VAC
	<a href="#">K21-35077</a>	TRANSFORMER, 575V, 24VAC
5	<a href="#">K29-31244</a>	RELAY, DPST, 24V, 30A
	<a href="#">K29-31245</a>	RELAY, 12V, 30A
6	<a href="#">K29-31229</a>	RELAY, 24VDC, 30A, SPDT, 1PH
7	<a href="#">K74-31243</a>	MOV KIT, L5, 1PH/3PH
8	<a href="#">K79-15016-1</a>	RPM SENSOR KIT
9	<a href="#">K001A6837</a>	LOGIC BOARD, L4
10	<a href="#">K002A0761</a>	RECEIVER COAXIAL CABLE, 315MHZ
11	<a href="#">K001C3196-3</a>	ANTENNA, 315MHZ
12	<a href="#">K42-31247</a>	TERMINAL BLOCK, 3 POSITION, 600V, 20A
13	<a href="#">K42-10040</a>	TERMINAL BLOCK, 3 POSITION
	<b>NOT SHOWN IN DIAGRAM</b>	
	<a href="#">K74-MODELH</a>	MAIN WIRE HARNESS

## SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	<a href="#">K72-14130-1</a>	LIMIT SHAFT KIT
K2	<a href="#">K72-12515-1</a>	LIMIT SWITCH KIT

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

# Models T, GT, APT, SD, GSD, GH

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



# Models T, GT, APT, SD, GSD, GH

## REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<a href="#">K13-10024</a>	LIMIT NUT
2	<a href="#">K23-10041</a>	LIMIT SWITCH, SPDT, 10A, 125/250VAC
3	<a href="#">K75-35627</a>	E.BOX, COVER, GH,GT,T,GT,GSD
4	<a href="#">K21-14182</a>	TRANSFORMER, 120/240V, 24VAC, 20VA
	<a href="#">K21-35057</a>	TRANSFORMER, 460V, 24VAC
	<a href="#">K21-35077</a>	TRANSFORMER, 575V, 24VAC
5	<a href="#">K29-31244</a>	RELAY, DPST, 24V, 30A
	<a href="#">K29-31245</a>	RELAY, 12V, 30A
6	<a href="#">K29-31229</a>	RELAY, 24VDC, 30A, SPDT, 1PH
7	<a href="#">K74-31243</a>	MOV KIT, L5, 1PH/3PH
8	<a href="#">K79-15016-1</a>	RPM SENSOR KIT
9	<a href="#">K001A6837</a>	LOGIC BOARD, L4
10	<a href="#">K002A0761</a>	RECEIVER COAXIAL CABLE, 315MHZ
11	<a href="#">K001C3196-3</a>	ANTENNA, 315MHZ
12	<a href="#">K42-31247</a>	TERMINAL BLOCK, 3 POSITION, 600V, 20A
13	<a href="#">K42-10040</a>	TERMINAL BLOCK, 3 POSITION
	<b>NOT SHOWN IN DIAGRAM</b>	
	<a href="#">K74-MODELH</a>	MAIN WIRE HARNESS

## SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	<a href="#">K72-10047</a>	LIMIT SHAFT ASSEMBLY KIT, T, APT, SD, GH
	<a href="#">K72-10047-1</a>	LIMIT SWITCH SHAFT KIT
K2	<a href="#">K72-12515-1</a>	LIMIT SWITCH KIT

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

# Models J, H, HJ

REPLACEMENT PARTS ————— KEY ITEMS + DIAGRAM



KEY#	PART#	DESCRIPTION
1	<u>K13-10024</u>	LIMIT NUT
2	<u>K23-10041</u>	LIMIT SWITCH, SPDT, 10A, 125/250VAC
3	<u>K75-36913</u>	COVER FOR CURRENT SENSE KIT, H, J, L5
4	<u>K21-14182</u>	TRANSFORMER, 120/240V, 24VAC, 20VA
	<u>K21-36793</u>	TRANSFORMER, 208/230/460V-20VA
	<u>K21-35077</u>	TRANSFORMER, 575V, 24VAC
5	<u>K74-31243</u>	MOV KIT, L5, 1PH/3PH
6	<u>K79-15016-1</u>	RPM SENSOR KIT
7	<u>K001D8395MC</u>	LOGIC BOARD, 1PH/3PH, CURRENT SENSE READY L5
8	<u>K002A0761</u>	RECEIVER COAXIAL CABLE, 315MHZ
9	<u>K001C8103-1</u>	ANTENNA
10	<u>K001D8396-1</u>	POWER BOARD, 115/230V, 1PH, L5
	<u>K001D8397</u>	POWER BOARD KIT, 3PH, L5
	<u>K001D8397-1</u>	POWER BOARD KIT, 575V, L5
11	<u>K21-38158</u>	CURRENT SENSE HARNESS, 3PH, L5
	<b>NOT SHOWN IN DIAGRAM</b>	
	<u>K94-36934</u>	MAIN WIRING HARNESS, L5

SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	<u>K72-14130-1</u>	LIMIT SHAFT KIT
K2	<u>K72-12515-1</u>	LIMIT SWITCH KIT

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

## Models T, GT, APT, SD, GSD, GH

REPLACEMENT PARTS ——— KEY ITEMS + PARTS LIST



KEY#	PART#	DESCRIPTION
1	<u>K13-10024</u>	LIMIT NUT
2	<u>K23-10041</u>	LIMIT SWITCH, SPDT, 10A, 125/250VAC
3	<u>K75-36914</u>	COVER FOR CURRENT SENSE KIT, GT, GH, L5
4	<u>K21-14182</u>	TRANSFORMER, 120/240V, 24VAC, 20VA
	<u>K21-36793</u>	TRANSFORMER, 208/230/460V-20VA
	<u>K21-35077</u>	TRANSFORMER, 575V, 24VAC
5	<u>K74-31243</u>	MOV KIT, L5, 1PH/3PH
6	<u>K79-15016-1</u>	RPM SENSOR KIT
7	<u>K001D8395MC</u>	LOGIC BOARD, 1PH/3PH, CURRENT SENSE READY L5
8	<u>K002A0761</u>	RECEIVER COAXIAL CABLE, 315MHZ
9	<u>K001C8103-1</u>	ANTENNA
10	<u>K001D8396-1</u>	POWER BOARD, 115/230V, 1PH, L5
	<u>K001D8397</u>	POWER BOARD KIT, 3PH, L5
	<u>K001D8397-1</u>	POWER BOARD KIT, 575V, L5
11	<u>K21-38158</u>	CURRENT SENSE HARNESS, 3PH, L5
	<b>NOT SHOWN IN DIAGRAM</b>	
	<u>K94-36934</u>	MAIN WIRING HARNESS, L5

SERVICE KITS ——— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	<u>K72-10047</u>	LIMIT SHAFT ASSEMBLY KIT, T, APT, SD, GH
	<u>K72-10047-1</u>	LIMIT SWITCH SHAFT KIT
K2	<u>K72-12515-1</u>	LIMIT SWITCH KIT

NOTE: Part numbers that are not highlighted are no longer available.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

## Models NEMA 4, N4X

## REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM




KEY#	PART#	DESCRIPTION
1	<a href="#">K03-35711</a>	CONTACTOR RELAY, 24V, 2NO+2NC
2	<a href="#">K21-7115-1</a>	TRANSFORMER, 115/230V, 1PH
	<a href="#">K21-7460</a>	TRANSFORMER, 240/480V, 3PH
	<a href="#">K21-7460-1</a>	TRANSFORMER, 230/460V, 3 PH
	<a href="#">K21-7575</a>	TRANSFORMER, 575V, 24VAC
	<a href="#">21-7575-1</a>	TRANSFORMER, 575V, 3PH
3	<a href="#">K001D8395MC</a>	LOGIC BOARD, 1PH/3PH, CURRENT SENSE READY L5
4	<a href="#">K52C0481</a>	BRIDGE RECTIFIER KIT
5	<a href="#">K42-31247</a>	TERMINAL BLOCK, 3 POSITION, 600V, 20A
6	<a href="#">K23-10041</a>	LIMIT SWITCH, SPDT, 10A, 125/250VAC
7	<a href="#">K72-12515-1</a>	LIMIT SWITCH KIT
8	<a href="#">K13-10024</a>	LIMIT NUT
9	<a href="#">K79-15016-1</a>	RPM SENSOR KIT
10	<a href="#">K72-33192</a>	LIMIT SHAFT KIT
	<a href="#">K72-33258</a>	LIMIT SHAFT AND SPROCKET
11	<a href="#">K75-37367</a>	ENCLOSURE AND COVER, GH, N4/N4X, L5
12	<a href="#">K29-ABC-2</a>	FUSE, 250V, 2A
13	<a href="#">K001C8103-1</a>	ANTENNA
14	<a href="#">K001D8398</a>	POWER BOARD KIT, 1PH, N4, L5
	<a href="#">K001D8116-1</a>	POWER BOARD, 230/460/575V, 3PH, NEMA, L5
15	<a href="#">AUXCARD</a>	OPTION CARD AUX RELAY KIT
	<b>NOT SHOWN IN DIAGRAM</b>	
	<a href="#">K94-37289</a>	WIRE HARNESS KIT, N4, LOW VOLTAGE, L5

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

## Models H, J, HJ, GH, GT, T, APT

REPLACEMENT PARTS ——— KEY ITEMS + PARTS LIST



KEY#	PART#	DESCRIPTION
1	<a href="#">K03-35711</a>	CONTACTOR RELAY, 24V, 2NO+2NC
2	<a href="#">K21-7115-1</a>	TRANSFORMER, 115/230V, 1PH
	<a href="#">K21-7460</a>	TRANSFORMER, 240/480V, 3PH
	<a href="#">K21-7460-1</a>	TRANSFORMER, 230/460V, 3 PH
	<a href="#">K21-7575</a>	TRANSFORMER, 575V, 24VAC
	<a href="#">21-7575-1</a>	TRANSFORMER, 575V, 3PH
3	<a href="#">K001A6837</a>	LOGIC BOARD, L4
4	<a href="#">K52C0481</a>	BRIDGE RECTIFIER KIT
5	<a href="#">K74-31243</a>	MOV KIT, L5, 1PH/3PH
6	<a href="#">K42-31247</a>	TERMINAL BLOCK, 3 POSITION, 600V, 20A
7	<a href="#">K23-10041</a>	LIMIT SWITCH, SPDT, 10A, 125/250VAC
8	<a href="#">K72-12515-1</a>	LIMIT SWITCH KIT
9	<a href="#">K13-10024</a>	LIMIT NUT
10	<a href="#">K79-15016-1</a>	RPM SENSOR KIT
11	<a href="#">K72-33192</a>	LIMIT SHAFT KIT
12	<a href="#">K75-35815</a>	ENCLOSURE, 1PH, N4
	<a href="#">K75-35816</a>	ENCLOSURE, 3PH, N4
13	<a href="#">K29-ABC-2</a>	FUSE, 250V, 2A
14	<a href="#">K74-19499</a>	ANTENNA
15	<a href="#">AUXCARD</a>	OPTION CARD AUX RELAY KIT


**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

# Models MT, BMT, MJ, MH, MHS, MGJ, E, U

POWERED BY myQ.

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



# Models MT, BMT, MJ, MH, MHS, MGJ, E, U

## REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K13-10024</u>	LIMIT NUT
2	<u>K23-10041</u>	LIMIT SWITCH, SPDT, 10A, 125/250VAC
3	<u>K29-10338</u>	MOTOR CAPACITOR, 70MFD, 50/60HZ, 230V
4	<u>K10-33850</u>	E-BOX, COVER, MH, MJ, MT
	<b>NOT SHOWN IN DIAGRAM</b>	
	<u>K75-36237</u>	MEDIUM DUTY STIFFENER KIT

## SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	<u>K72-33872-1</u>	LIMIT SWITCH SHAFT AND SPROCKET
	<u>K72-33872-2</u>	LIMIT SWITCH SHAFT KIT
K2	<u>K72-12493</u>	LIMIT SWITCH KIT
K3	<u>K94-33961</u>	WIRE HARNESS KIT, MT, MJ, MH
K4	<u>K001A6424</u>	LOGIC BOARD, MEDIUM DUTY, U, 315MHZ
	<u>K001A6424-1</u>	LOGIC BOARD, MEDIUM DUTY, U, 390MHZ
	<u>K001A6424-2</u>	LOGIC BOARD, MEDIUM DUTY, E, 315MHZ
	<u>K001A6424-3</u>	LOGIC BOARD, MEDIUM DUTY, E, 390MHZ
K5	<u>K74-31243</u>	MOV KIT, L5, 1PH/3PH

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](https://Partner.LiftMaster.com)

# Contactor Style

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



# Contactor Style

## REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K03-8024-K</u>	REVERSING CONTACTOR
2	<u>10-10020M1</u>	E-BOX, H, J, T
	<u>10-13900M1</u>	E-BOX, GH, GSD
3	<u>K75-14347</u>	E-BOX, COVER
	<u>K75-10128</u>	LOW PROFILE COVER
4	<u>K21-5115</u>	TRANSFORMER, 115/240V
	<u>K21-5230</u>	TRANSFORMER, 208/240V, 24VAC, 40VA
	<u>K21-5460</u>	TRANSFORMER, 460V
5	<u>K23-10916</u>	INTERLOCK SWITCH, 125/250VAC, 15A, SPDT
6	<u>K24-24-1</u>	RELAY, 24V, 10A
7	<u>K24-115-1</u>	RELAY, 120V, 10A
	<u>K24-230-5</u>	RELAY, 3PDT, 230V, 7A
8	<u>K25-2006</u>	OVERLOAD, 6A
	<u>K25-2008</u>	OVERLOAD, 8A
	<u>K25-2010</u>	OVERLOAD, 10A
	<u>K25-2015</u>	OVERLOAD, 15A
	<u>K25-2020</u>	OVERLOAD, 20A
9	<u>K25-4002-5K</u>	OVERLOAD, 1.8-2.6A
	<u>K25-4003-K</u>	OVERLOAD, 2.6-3.7A
	<u>K25-4004-K</u>	OVERLOAD, 3.7-5.5A
	<u>K25-4008-K</u>	OVERLOAD, 5.5-8.0A
	<u>K25-4011-5K</u>	OVERLOAD, 8.0-11.5A
10	<u>K42-10040</u>	TERMINAL BLOCK, 3 POSITION
11	<u>K42-110</u>	TERMINAL BLOCK, 10 POSITION, 600V, 30A
12	<u>25-3000-K</u>	OVERLOAD BRACKET
	<b>NOT SHOWN IN DIAGRAM</b>	
	<u>K72-14130-1</u>	LIMIT SHAFT KIT (H, J, & GH)
	<u>K19-48033M</u>	CHAIN, #48X33, WITH ML

## SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
L	<u>K72-12510</u>	LIMIT SHAFT KIT, LOW PROFILE E-BOX (T & GT)
L1	<u>K11-10021</u>	LIMIT SHAFT
L2	<u>K13-10024</u>	LIMIT NUT
S	<u>K75-12511</u>	LIMIT SWITCH KIT
S1	<u>K23-10041</u>	LIMIT SWITCH, SPDT, 10A, 125/250VAC

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

# Models MT, BMT, MJ, MH

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



# Models MT, BMT, MJ, MH

## REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K10-10315M1</u>	E-BOX, MT
2	<u>10-10316M</u>	E-BOX COVER
3	<u>K23-10916</u>	INTERLOCK SWITCH, 125/250VAC, 15A, SPDT
4	<u>K29-2</u>	RESISTOR, 25W, 10%, 2 OHM
5	<u>K42-10040</u>	TERMINAL BLOCK, 3 POSITION
6	<u>K42-110</u>	TERMINAL BLOCK, 10 POSITION, 600V, 30A
7	<u>K71-10345</u>	RPM SENSOR BOARD, MT
8	<u>K74-10352</u>	RPM SENSOR BOARD HARNESS
9	<u>K21-10340</u>	TRANSFORMER, 115V, 24VAC, 20VA
	<u>K21-5230</u>	TRANSFORMER, 208/240V, 24VAC, 40VA
10	<u>K24-24-1</u>	RELAY, 24V, 10A
	<u>K24-24-6</u>	RELAY, 3PDT, 24V, 10A
11	<u>K29-10338</u>	MOTOR CAPACITOR, 70MFD, 50/60HZ, 230V
	<u>K29-12110</u>	CAPACITOR, 20UF, 230V
11	<u>K80-10027</u>	LOGIC BOARD STANDOFF
	<b>NOT SHOWN IN DIAGRAM</b>	
	<u>K31-10350</u>	RPM BOARD STANDOFFS, QTY. 6
	<u>K75-12489</u>	LOGIC BOARD, AUTO REVERSAL

## SERVICE KITS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
L	<u>K72-12487</u>	LIMIT SHAFT KIT
L1	<u>K11-10321</u>	LIMIT SHAFT
L2	<u>K13-10024</u>	LIMIT NUT
S	<u>K72-12487</u>	LIMIT SHAFT KIT
S1	<u>K23-10041</u>	LIMIT SWITCH, SPDT, 10A, 125/250VAC

## COMPLETE ELECTRICAL BOX ————— KITS + PARTS LIST


PART#	DESCRIPTION
<b>NOT SHOWN IN DIAGRAM</b>	
<u>K-MJ5011</u>	E-BOX, MJ5011
<u>K-MJ5025</u>	E-BOX, 230V
<u>K-MH5025R</u>	E-BOX, MGJ5025R
<u>K-MH5025L</u>	E-BOX, MGJ5025L
<u>K-MT5011</u>	E-BOX, MT5011
<u>K-MT5025</u>	E-BOX, 230V, 50HZ
<u>K-BMT5011</u>	E-BOX, BMT5011
<u>K-BMT5025</u>	E-BOX, 230V, BMT5025

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

# Model MGJ

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



## Model MGJ

## REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
2	<u>K10-11403M</u>	E-BOX, COVER, MGJ
3	<u>10-11420M1</u>	E-BOX, MGJ
4	10-11421	CAPACITOR CLAMP
5	<u>K21-5115</u>	TRANSFORMER, 115/240V
6	<u>K24-24-1</u>	RELAY, 24V ,10A
7	<u>K29-10338</u>	MOTOR CAPACITOR, 70MFD, 50/60HZ, 230V
8	<u>K29-2</u>	RESISTOR, 25W, 10%, 2 OHM
9	<u>K42-10040</u>	TERMINAL BLOCK, 3 POSITION
10	<u>K42-110</u>	TERMINAL BLOCK, 10 POSITION, 600V, 30A

## REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST FOR 3-PHASE

KEY#	PART#	DESCRIPTION
1	<u>K03-8024-K</u>	REVERSING CONTACTOR
2	<u>K10-11403M</u>	E-BOX, COVER, MGJ
3	<u>10-11420M1</u>	E-BOX, MGJ
5	<u>K21-5230</u>	TRANSFORMER, 208/240V, 24VAC, 40VA
	<u>K21-5460</u>	TRANSFORMER, 460V
6	<u>K24-24-1</u>	RELAY, 24V ,10A
9	<u>K42-10040</u>	TERMINAL BLOCK, 3 POSITION
10	<u>K42-110</u>	TERMINAL BLOCK, 10 POSITION, 600V, 30A

## SERVICE KITS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
L	<u>K72-12565</u>	LIMIT SHAFT KIT, MGJ
L1	11-11373	LIMIT SHAFT
L2	<u>K13-10024</u>	LIMIT NUT
S	<u>K75-12566</u>	LIMIT SWITCH KIT, MGJ
S1	<u>K23-10041</u>	LIMIT SWITCH, SPDT, 10A, 125/250VAC

## COMPLETE ELECTRICAL BOX ————— KITS + PARTS LIST


PART#	DESCRIPTION
<b>NOT SHOWN IN DIAGRAM</b>	
<u>K-MGJ5011</u>	E-BOX, MGJ5011
<u>K-MGJ5023</u>	E-BOX, MGJ5023

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)

## Model GH 5HP

## REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



KEY#	PART#	DESCRIPTION
1	03-8224D	CONTACTOR
2	03-ABDIN-4	DIN RAIL, 4"
3	<u>K21-3460-1</u>	TRANSFORMER, 230/460V PRIM, 24SEC
	<u>K21-3575-1</u>	TRANSFORMER, 575V, PRIM 24, SEC 100
4	<u>K24-24-1</u>	RELAY, 24V, 10A
5	<u>K24-264-1</u>	RELAY, 24V, DC, DSPT
6	<u>K25-4018-D</u>	OVERLOAD, 12-18A
	<u>K25-4010-D</u>	OVERLOAD, 7.0-10.0A
	<u>K25-4008-D</u>	OVERLOAD, 5.5-8.0A
7	<u>K27-8002-D</u>	AUXILIARY CONTACT BLOCK RELAY, 1 NO/1 NC
8	<u>35-204</u>	FUSE, 125V, 4A
9	<u>K42-114</u>	TERMINAL BLOCK, 14 POSITION, 600V, 30A

## SERVICE KITS ——— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
L	<u>K74-18346</u>	LIMIT SHAFT KIT
L1	<u>K11-10480</u>	LIMIT SHAFT, CARWASH
L2	<u>K13-10024</u>	LIMIT NUT
S	<u>K72-18345</u>	LIMIT SWITCH KIT
S1	<u>K23-10041</u>	LIMIT SWITCH, SPDT, 10A, 125/250VAC

**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [Partner.LiftMaster.com](http://Partner.LiftMaster.com)