


CSL24U, CSL24UL, CSL24ULWK

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



CSL24U, CSL24UL, CSL24ULWK

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	K15-41B17LKGH	OUTPUT SPROCKET
2	K32-34669-1	GEAR REDUCER, 10:1, #60
3	K16-GT2-7	TIMING BELT
4	K1A6408	APE KIT, 24V
5	29-NP712	BATTERY, 12V, 7AH
6	K94-35152	PIEZO ALARM
7	K1D8389-1CC	MAIN BOARD, DC PAD-MOUNTS, UL325
8	K1D8387-1CC	EXPANSION BOARD, UL325
9	K13-34729	E-BOX COVER
10	K77-36541	ANTENNA
11	K76-34728	EMI BOARD WITH POWER SWITCH
12	K180A0357	RESET SWITCH
13	K77-36542	E-BOX
14	K73-34718-5	CHASSIS
15	K204C0211	TRANSFORMER
16	K52C0481	BRIDGE RECTIFIER KIT
17	K75-50090	IDLER PULLEY, Q013
18	K76-36398	MOTOR, 1/2HP, 24VDC
19	K10-34758-2	HEATER BATTERY BRACKET
20	K77-37852	COVER, GRAY, CSL24U
	K77-39426	COVER, GRAY CSL24UL
21	K75-36260	LOCK AND KEYS
22	K80-50295	ACCESS DOOR KEYS, QTY 2, Q118
	NOT SHOWN IN DIAGRAM	
	K1D8389-1CCU	UPGRADE KIT WITH EYES, DC PAD, UL325
	77-36764	CRANK BRACKET KIT
	K07-50637	CHAIN BOLT, Q003
	K94-34778	BOARD TO BOARD WIRE HARNESS, 24V
	K94-36531	RESET SWITCH WITH ID RESISTOR KIT
	K94-37205	BATTERY HARNESS, 7AH, CSL24V, CSW24V
	K80-3001	BOLT, 5/16"-18X32

SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	K17-36530	GEAR REDUCER AND MOTOR PULLEY KIT
K2	K74-30762	BATTERY PACK, 12V, 7AH, QTY. 2
K3	K76-34697	APS ENCODER KIT, 24V
K4	K77-37856	COVER, GRAY, RSW12U, CSL24U, CSW24U
	NOT SHOWN IN DIAGRAM	
	LMWEKITU	MONITORED WIRELESS EDGE KIT

NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

CSL24VDC

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



CSL24VDC

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	K16-GT2-7	TIMING BELT
2	K1A6408	APE KIT, 24V
3	K94-35152	PIEZO ALARM
4	K1D8059-1CC	CONTROL BOARD
5	K1D8080-1CC	EXPANSION BOARD, LA500, CSW24V, CSL24V
6	K13-34729	E-BOX COVER
7	K77-36541	ANTENNA
8	K76-34728	EMI BOARD WITH POWER SWITCH
9	K180A0357	RESET SWITCH
10	K77-36542	E-BOX
11	K73-34718-5	CHASSIS
12	K204C0211	TRANSFORMER
13	K52C0481	BRIDGE RECTIFIER KIT
14	K76-36398	MOTOR, 1/2HP, 24VDC
15	K32-34669-1	GEAR REDUCER, 10:1, #60
16	K15-41B17LKGH	OUTPUT SPROCKET
17	K75-50090	IDLER PULLEY, Q013
18	K75-36260	LOCK AND KEYS
19	K80-50295	ACCESS DOOR KEYS, QTY 2, Q118
20	29-NP712	BATTERY, 12V, 7AH
21	K10-34758-2	HEATER BATTERY BRACKET
	NOT SHOWN IN DIAGRAM	
	K1D8389-1CCU	UPGRADE KIT WITH EYES, DC PAD, UL325
	77-36764	CRANK BRACKET KIT
	K94-36250	BATTERY WIRE HARNESS, 7AH
	K94-36531	RESET SWITCH WITH ID RESISTOR KIT
	K94-36596	BATTERY WIRE HARNESS, 33AH
	K94-37205	BATTERY HARNESS, 7AH, CSL24V, CSW24V
	K07-50637	CHAIN BOLT, Q003
	K80-3001	BOLT, 5/16"-18X32
	ACCESSORIES	
	19-41240D	DRIVE CHAIN #41, 10'
	19-50307	MASTER LINK, #41, CHAIN, ROLLER, ST, BO

SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	K17-36530	GEAR REDUCER AND MOTOR PULLEY KIT
K2	K76-34697	APS ENCODER KIT, 24V
K3	K74-30762	BATTERY PACK, 12V, 7A
K4	K77-37183	COVER, CSL24V

NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

CSL24V, CSL24VH

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



CSL24V, CSL24VH

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K16-GT2-7</u>	TIMING BELT
2	<u>K1A6408</u>	APE KIT, 24V
3	<u>K94-35152</u>	PIEZO ALARM
4	<u>K1D6597-1CC</u>	CONTROL BOARD, CSL24V, CSW24V
5	<u>K1D6686CC</u>	EXPANSION BOARD, CSL24V
6	<u>K13-34729</u>	E-BOX COVER
7	<u>K77-36541</u>	ANTENNA
8	<u>K76-34728</u>	EMI BOARD WITH POWER SWITCH
9	<u>K180A0357</u>	RESET SWITCH
10	<u>K77-36542</u>	E-BOX
11	<u>K73-34718-2</u>	CHASSIS
12	<u>K204C0211</u>	TRANSFORMER
13	<u>K52C0481</u>	BRIDGE RECTIFIER KIT
14	<u>K76-36398</u>	MOTOR, 1/2HP, 24VDC
15	<u>K32-34669-1</u>	GEAR REDUCER, 10:1, #60
16	<u>K15-41B17LKGH</u>	OUTPUT SPROCKET
17	<u>K75-50090</u>	IDLER PULLEY, Q013
18	<u>K75-36260</u>	LOCK AND KEYS
19	<u>K80-50295</u>	ACCESS DOOR KEYS, QTY 2, Q118
20	<u>29-NP712</u>	BATTERY, 12V, 7AH
21	<u>K10-34758-2</u>	HEATER BATTERY BRACKET
	NOT SHOWN IN DIAGRAM	
	<u>K1D8389-1CCU</u>	UPGRADE KIT WITH EYES, DC PAD, UL325
	<u>77-36764</u>	CRANK BRACKET KIT
	<u>K94-36250</u>	BATTERY WIRE HARNESS, 7AH
	<u>K94-36531</u>	RESET SWITCH WITH ID RESISTOR KIT
	<u>K94-36596</u>	BATTERY WIRE HARNESS, 33AH
	<u>K94-37205</u>	BATTERY HARNESS, 7AH, CSL24V, CSW24V
	<u>K07-50637</u>	CHAIN BOLT, Q003
	<u>K80-3001</u>	BOLT, 5/16"-18X32
	ACCESSORIES	
	<u>19-41240D</u>	DRIVE CHAIN #41, 10'
	<u>19-50307</u>	MASTER LINK, #41, CHAIN, ROLLER, ST, BO

SERVICE KITS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
K1	<u>K17-36530</u>	GEAR REDUCER AND MOTOR PULLEY KIT
K2	<u>K76-34697</u>	APS ENCODER KIT, 24V
K3	<u>K74-30762</u>	BATTERY PACK, 12V, 7A
K4	<u>K77-37183</u>	COVER, CSL24V


NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

SL3000, SL3000ULE - OMNI

POWERED BY myQ.

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



SL3000, SL3000ULE - OMNI

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	K09-50087	CHASSIS, Q005
2	K80-50044	CONTROL BOARD STANDOFFS, QTY 3
3	K15-41B26LGH	DRIVE SPROCKET, Q014
4	K32-50091	GEAR REDUCER, 30:1, Q015
5	K15-35B17LGF	LIMIT SWITCH SPROCKET, Q016
6	K20-1050B-1RL	MOTOR, 1/2HP, 115V, 1PH, BM
7	K16-50094	V-BELT, 4L220, Q020
8	K17-50095	GEAR PULLEY, 2 1/2" OD, 5/8" BORE, Q021
9	K17-50098	MOTOR PULLEY, 2-1/2" OD, 1/2" BORE, Q025
10	K29C-65AU2415	MOTOR CAPACITOR, Q027
11	K07-50303	MANUAL CRANK, Q028
12	K23-50099	LIMIT SWITCH
13	K19-35052	LIMIT SWITCH CHAIN, #35, Q030
14	K16-50105	V-BELT, 4L340, Q039
15	K75-50242	CRANK INPUT, Q237
16	K75-51048	COVER WITH CRANK HOUSING, Q254
	K13-51216	COVER, SL3000E
17	Q400E	MAIN CONTROL BOARD, OMNI
	OMNIUP	CONTROL BOARD, OMNI
18	K-001A5872	CONTROL BOARD, 1HP, Q401
19	K29-50279	ALARM, Q404
20	K94-50281	WIRE HARNESS KIT, 1HP MOTOR, Q407
21	K74-50282	SWITCH CHANNEL, Q408
22	K41-50283	E-BOX COVER, Q409
23	K94-50286-1	WIRE HARNESS KIT, SL MOTOR, Q420
24	K94-50287-1	WIRE HARNESS KIT, SL-DM, Q421
25	K75-50090	IDLER PULLEY, Q013
26	K75-50893	SAFETY INTERLINK KIT
27	K75-50932	CRANK HOUSING KIT
28	K23-51158	RESET SWITCH
29	K19-40ML	MASTER LINK, #40
	K19-41ML-NP	MASTER LINK, #41
30	K70-51060	SURGE PROTECTOR, Q410
31	K74-50278	E-BOX ASSEMBLY, Q403
	NOT SHOWN IN DIAGRAM	
	K71-50183	LONG GATE CHAIN AND SPROCKET KIT, Q160
	K17-51210	PULLEY, 7-5/8" OD, 3/4" BORE, 4L BELT
	K16-20424	BELT, 4L430
	K16-51209	BELT, 4L315
	K76-51230	BRAKE SOLENOID
	02-51227	STOP RESET SWITCH
	K94-37467	OMNI SIREN, ALARM
	24-51233	BRAKE SOLENOID RELAY

SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
A	K75-50097	LIMIT SWITCH KIT, Q024
1A	K11-50100	LIMIT SWITCH SHAFT, Q031
2A	K75-50101	LIMIT NUT
3A	K15-35B09AXR	LIMIT SWITCH SPROCKET, Q033
4A	K75-50156	LIMIT SWITCH BEARING KIT, Q101
5A	K07-50180	COLLAR. 3/8" ID, Q156
B	DC2000SL	BATTERY BACKUP, SL DC2000
1B	K16-50123	V-BELT, 4L400, Q065
2B	K20-9012B-1	MOTOR, 12VDC
3B	K75-50170	MOTOR MOUNTING PLATE, Q143
4B	K16-50187	V-BELT, 4L370, Q164
5B	K17-50223	GEAR REDUCER PULLEY, Q209
6B	K94-50262	WIRE HARNESS KIT, DC2000, Q277
7B	DC2000	CONTROLLER, DC2000
C	77-36764	CRANK BRACKET KIT
1C	K07-50637	CHAIN BOLT, Q003

NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

SL3000U, SL3000UL

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



SL3000U, SL3000UL

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K77-37708</u>	COVER, SL3000AC
2	<u>K17-50095</u>	GEAR PULLEY, 2 1/2" OD, 5/8" BORE, Q021
3	<u>K16-4L230</u>	DRIVE BELT, 1/2HP
4	<u>K16-4L360</u>	DRIVE BELT, 1HP
5	<u>K17-50098</u>	MOTOR PULLEY, 2-1/2" OD, 1/2" BORE, Q025
6 & 7	<u>K20-1050B-1RSX</u>	MOTOR, 1/2HP, AC
8	<u>K73-37199</u>	CHASSIS, SL3000
9	<u>K77-37710</u>	BRAKE KIT
10	<u>K1D8387-1CC</u>	EXPANSION BOARD, UL325
11	<u>K1D8402-1CC</u>	MOTOR DRIVE BOARD, 1PH, SL3000, CSW200
12	<u>K21-14182</u>	TRANSFORMER, 120/240V, 24VAC, 20VA
13	<u>K29C-65AU2415</u>	MOTOR CAPACITOR, Q027
14	<u>K32-37349</u>	GEAR REDUCER AND BRAKE
15	<u>K94-37461</u>	ALARM AND HARNESS
16	<u>K13-34729</u>	E-BOX COVER
17	<u>K77-37638</u>	ANTENNA AND COAX CABLE
18	<u>K75-50090</u>	IDLER PULLEY, Q013
19	<u>K15-35B17LGF</u>	LIMIT SWITCH SPROCKET, Q016
20	<u>K15-41B25LGH</u>	DRIVE SPROCKET
21	<u>K19-35056</u>	LIMIT SWITCH CHAIN
22	<u>K15-35B13AXR</u>	LIMIT SWITCH SPROCKET
23	<u>K23-50099</u>	LIMIT SWITCH
24	<u>K13-32087</u>	RPM CUP
NOT SHOWN IN DIAGRAM		
	<u>K2A0878</u>	HALL EFFECT BOARD
	<u>K19-40ML</u>	MASTER LINK, #40
	<u>K07-50637</u>	CHAIN BOLT, Q003
	<u>77-36764</u>	CRANK BRACKET KIT
	<u>K77-37683</u>	MAIN BOARD STANDOFFS, QTY 10
	<u>K77-37693</u>	WIRE HARNESES, AC, CSW200, SL3000
	<u>K94-34778</u>	BOARD TO BOARD WIRE HARNESS, 24V
	<u>K94-37468</u>	RESET SWITCH KIT, WITH ID

SERVICE KITS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
K1	<u>K76-37306</u>	LIMIT SWITCH KIT
K2	<u>K75-37300-1</u>	E-BOX
K3	<u>K77-37709</u>	ON/OFF SWITCH AND RECEPTACLE BOX
K4	<u>K1D6761-1CC</u>	LOGIC BOARD, AC, WITH MOUNTING BRACKET


NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

SL575, SL575GL

POWERED BY myQ.

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



SL575, SL575GL

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K22-120</u>	BRAKE SOLENOID, 120V
	<u>K22-240</u>	BRAKE SOLENOID, 240V
	<u>K22-575-1</u>	BRAKE SOLENOID, 575V
2	<u>K80-9001</u>	FEATHER KEY
3	<u>K12-4164</u>	FLANGED BEARING, SELF ALIGNING
4	<u>K15-19478</u>	SPROCKET, 48B32T, 1-1/2"B
5	<u>K10-30678</u>	LOCK BAR
6	<u>K23-34815</u>	RESET SWITCH
7	<u>K16-5L304</u>	V BELT, 30-1/32"
8	<u>K17-6014</u>	PULLEY, 2" OD, 5/8"B
9	<u>K20-1100B-2P</u>	MOTOR, 1HP, 115/230V, 1PH, BM
	<u>K20-1050B-2P</u>	MOTOR, 1/2HP, 115/230V, 1PH, BM
	<u>K20-3050B-4P</u>	MOTOR, 1/2HP, 230/460V, 3PH, BM
	<u>K20-3100B-4P</u>	MOTOR, 1HP, 230/460V, 3PH, BM
	<u>K20-3050M-5</u>	MOTOR, 1/2HP, 575V, 3PH, BM/CF
	<u>K20-3100M-5-H25</u>	MOTOR, 1HP, 3PH, L5
10	<u>K23-3001</u>	ON/OFF SWITCH, 125/277VAC, 20A
	<u>K23-3005</u>	ON/OFF SWITCH, 125/277VAC, 20A
11	<u>10-3504-B</u>	ANGLE BRACKET
	NOT SHOWN IN DIAGRAM	
	<u>K19-48047M</u>	CHAIN, #48X47
	<u>K001C3196-3</u>	ANTENNA, 315MHZ
	<u>K77-34846</u>	HARDWARE KIT, SL575, SL585, SL595
	<u>K19-48049MB</u>	CHAIN, #48X49
	<u>K23-30716</u>	STOP SWITCH, 125VAC, 6A

SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	<u>K71-B120</u>	INTERNAL BRAKE SOLENOID, 120V
	<u>K71-B240</u>	INTERNAL BRAKE SOLENOID, 240V
	<u>K71-B575</u>	INTERNAL BRAKE SOLENOID, 575V
K2	<u>K75-34824</u>	CHAIN GUARD KIT
K3	<u>K75-34828</u>	IDLER SHAFT KIT
K4	<u>K75-34842</u>	COVER, SL575, SL585
K5	<u>K29-32410</u>	ALARM KIT
K6	<u>K75-19977</u>	ARM KIT
K7	<u>K72-34844</u>	OUTPUT SHAFT KIT
K8	<u>K72-34845</u>	CLUTCH SHAFT KIT
K9	<u>K75-18493</u>	CHAIN GUIDE KIT

NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

SL585, SL585GL

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



SL585, SL585GL

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	K22-120	BRAKE SOLENOID, 120V
	K22-240	BRAKE SOLENOID, 240V
	K22-575-1	BRAKE SOLENOID, 575V
2	K80-14414	FEATHER KEY KIT
3	K12-4164	FLANGED BEARING, SELF ALIGNING
4	15-50B12LGH	SPROCKET, 50B12, 1"
5	K10-30678	LOCK BAR
6	K23-34815	RESET SWITCH
7	K32-34792	GEAR REDUCER, 30:1
8	K39-34786	CLUTCH DISK
9	K20-1050C-2P	MOTOR, 1/2HP, 115/230V, 1PH, CF
	K20-3050C-4P	MOTOR, 1/2HP, 230/460V, 3PH, CF
	K20-3050M-5	MOTOR, 1/2HP, 575V, 3PH, BM/CF
	K20-1100C-2P	MOTOR, 1HP, 115/230V, 1PH, CF
	K20-1150C-2P	MOTOR, 1-1/2HP, 115/230V, 1PH, CF
	K20-3100C-4P	MOTOR, 1HP, 230/460V, 3PH, CF
10	K23-20088	MOTOR, 1HP, 3PH, L5
	K23-3001	ON/OFF SWITCH, 120VAC, 15A
	K23-3005	ON/OFF SWITCH, 125/277VAC, 20A
11	10-3504-B	ON/OFF SWITCH, 125/277VAC, 20A
12	K10-30681M1	ANGLE BRACKET
		E-BOX BRACKET
	NOT SHOWN IN DIAGRAM	
	K03-8024-K	REVERSING CONTACTOR
	K21-3260-1	TRANSFORMER, 120/208/230/460/60VA
	K19-48055MB	CHAIN, #48X55
	K23-30716	STOP SWITCH, 125VAC, 6A

SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
K1	K75-10177	BRAKE HUB KIT
K2	K75-34828	IDLER SHAFT KIT
K3	K75-34824	CHAIN GUARD KIT
K4	K75-34842	COVER, SL575, SL585
K5	K75-34790	DISCONNECT KIT, SL585
K6	K75-34791	CLUTCH KIT, SL585
K7	K29-32410	ALARM KIT
K8	K75-18493	CHAIN GUIDE KIT
K9	K74-34821	RESET SWITCH
	NOT SHOWN IN DIAGRAM	
	71-6532448	HEATER KIT MODIFICATION, 230V
	K50-18423	HEATER KIT
	K77-34846	HARDWARE KIT, SL575, SL585, SL595
	K13-19441	VENT PLUG, SL585U
	K35-310-032-1	FUSE KIT

NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

SL585U, SL585UL

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



SL585U, SL585UL

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K74-39295-1</u>	E-BOX, SL585501U, SL585101U, SL585151U
	<u>K74-39295-2</u>	E-BOX, SL585503U, SL585103U
	<u>K74-39295-3</u>	E-BOX, SL585505U, SL585105U
2	<u>K76-37667-1</u>	LIMIT BOX KIT
3	<u>K13-32087</u>	RPM CUP
4	<u>K13-10024</u>	LIMIT NUT
5	<u>K23-10041</u>	LIMIT SWITCH, 10A, 125/250VAC
6	<u>K1D6761-1CC</u>	LOGIC BOARD, AC
7	<u>K21-3260-1</u>	TRANSFORMER, 120/208/230/460/60VA
	<u>K204A0276</u>	TRANSFORMER, 575VAC, 200VA
8	<u>K1D8387-1CC</u>	EXPANSION BOARD, UL325
9	<u>K1D8284-1CC</u>	MOTOR DRIVE BOARD, 1PH, SL585U, SL595U
	<u>K1D8424-1CC</u>	POWER BOARD, 3PH, SL585U, SL595U
	NOT SHOWN IN DIAGRAM	
	<u>K2A0878</u>	HALL EFFECT BOARD
	<u>K75-37670</u>	LIMIT SHAFT AND SPROCKET KIT, SL585U
	<u>K77-38121</u>	WIRE HARNESS, SL585U, SL595U
	<u>K94-38062-1</u>	POWER BOARD ID RESISTOR, 1/2HP, 3PH
	<u>K94-38062-2</u>	POWER BOARD ID RESISTOR, 1HP, 3PH
	<u>K94-38062-4</u>	POWER BOARD ID RESISTOR, 1/2HP, 575V
	<u>K94-38062-5</u>	POWER BOARD ID RESISTOR, 1HP, 575V

SERVICE KITS ————— KEY ITEMS + PARTS LIST


KEY#	PART#	DESCRIPTION
10	<u>K75-37576</u>	COVER KIT
11	<u>K75-34791</u>	CLUTCH KIT, SL585
12	<u>K19-48069-NP</u>	LIMIT CHAIN KIT, #48X69, NP
13	<u>K32-34792</u>	GEAR REDUCER, 30:1
14	<u>K39-34786</u>	CLUTCH DISK
15	<u>K94-37754</u>	ALARM KIT, SL585U
16	<u>K94-37694-1</u>	MOTOR, SL585501U
	<u>K94-37695</u>	MOTOR, SL585503U
	<u>K94-37739-1</u>	MOTOR AND HARNESS KIT, SL585505U
	<u>K94-37694-2</u>	MOTOR, SL585101U
	<u>K94-37766</u>	MOTOR, SL585103U
	<u>K94-37739-2</u>	MOTOR AND HARNESS KIT, SL585105U
	<u>K94-37694-3</u>	MOTOR, SL585151U
	<u>K23-34815-1</u>	RESET SWITCH
	<u>K76-38057</u>	HEATER KIT, 575V, SL585505U, SL585105U
17	<u>K75-34790</u>	DISCONNECT KIT
18	<u>K75-38037</u>	LATCH COVER AND SWITCH, 1PH
19	<u>K75-18493</u>	CHAIN GUIDE KIT
20	<u>K75-34828</u>	IDLER SHAFT KIT
21	<u>K12-4164</u>	FLANGED BEARING, SELF ALIGNING
22	<u>15-50B12LGH</u>	SPROCKET, 50B12, 1"
23	<u>K71-B1PH-1</u>	BRAKE SOLENOID, 120/240V, SL585U/SL595U
	<u>K71-B3PH-1</u>	BRAKE SOLENOID, 240V, 3PH
	<u>K71-B3PH</u>	INTERNAL BRAKE SOLENOID, 208/230V, 3PH
	<u>K71-B575</u>	INTERNAL BRAKE SOLENOID, 575V
24	<u>K22-120</u>	BRAKE SOLENOID, 120V
	<u>K22-575-1</u>	BRAKE SOLENOID, 575V
	<u>K22-36900</u>	BRAKE SOLENOID, 3PH, L5
25	<u>K75-10177</u>	BRAKE HUB KIT
	NOT SHOWN IN DIAGRAM	
	<u>K10-3209</u>	GATE BRACKET
	<u>K11-3503</u>	TAKE UP BOLT
	<u>19-3025</u>	CHAIN, #50X471, NP
	<u>K75-34824</u>	CHAIN GUARD KIT
	<u>K80-9001</u>	FEATHER KEY
	<u>K94-37753</u>	RESET SWITCH, WITH ID HARNESS KIT

NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

SL595, SL595GL

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



SL595, SL595GL

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION	
1	K20-1050C-2P	MOTOR, 1/2HP, 115/230V, 1PH, CF	
	K20-3050C-4P	MOTOR, 1/2HP, 230/460V, 3PH, CF	
	K20-3050M-5	MOTOR, 1/2HP, 575V, 3PH, BM/CF	
	K20-1100C-2P	MOTOR, 1HP, 115/230V, 1PH, CF	
	K20-1150C-2P	MOTOR, 1-1/2HP, 115/230V, 1PH, CF	
	K20-3100C-4P	MOTOR, 1HP, 230/460V, 3PH, CF	
	K20-3100M-5-H25	MOTOR, 1HP, 3PH, L5	
	K20-3200C-5	MOTOR, 2HP, 575V, 3PH, CF	
	K20-3200C-4P	MOTOR, 2HP, 230/460V, 3PH, CF	
	2	K32-10540	GEAR REDUCER, 20:1
	3	10-30702M	CHAIN GUARD
4	K11-3602	IDLER SHAFT	
5	K15-3619	SPROCKET, 50B19T, 1-1/4"X1/4"	
6	K305-153613	IDLER SPROCKET	
7	K10-3209	GATE BRACKET	
8	K11-3503	TAKE UP BOLT	
9	19-3025	CHAIN, #50X471, NP	
10	44-30703	ENCLOSURE, SL595	
11	K82-QN43-12	SCREW, 7/16"-14X12	
12	K91-G0149	IDLER BOLT	
13	10-30699	MOUNTING BRACKET	
14	K001C3196-3	ANTENNA, 315MHZ	
15	K23-2016	LIMIT SWITCH	
16	K13-10024	LIMIT NUT	
17	K74-G0589	HALL EFFECT SENSOR KIT	
18	K12-3601	PILLOW BLOCK BEARING	
19	K39-10541	CLUTCH DISK	
20	K19-4853	CHAIN, #48X53, NO ML	
21	19-4071	CHAIN, #40X71, NO ML	
22	K19-40ML	MASTER LINK, #40	
23	K23-3001	ON/OFF SWITCH, 125/277VAC, 20A	
	K23-3005	ON/OFF SWITCH, 125/277VAC, 20A	
NOT SHOWN IN DIAGRAM			
	K23-34815	RESET SWITCH	
	K80-33800	PADLOCK KIT	
	K23-30716	STOP SWITCH, 125VAC, 6A	
	K87-E-118	E-RING, IDLER SHAFT	

SERVICE KITS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
K1	K75-18618	DISCONNECT KIT
K2	K75-12858	TORQUE LIMITER ASSEMBLY
K3	K75-18620	LIMIT BOX, SL595
K4	K72-18615	DRIVE SHAFT KIT
K5	K75-18493	CHAIN GUIDE KIT
NOT SHOWN IN DIAGRAM		
	71-6532448	HEATER KIT MODIFICATION, 230V
	K29-32410	ALARM KIT
	K50-18423	HEATER KIT
	K77-36502	VARIABLE SPEED CONTROLLER


NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com

SL595U, SL595UL

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM

ELECTRICAL BOX ASSEMBLY
 K74-39299-1 SL595101UL and SL595151UL
 K74-39299-2 SL595103UL and SL595203UL
 K74-39299-3 SL595105UL and SL595205UL



SL595U, SL595UL

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K1D6761-1CC</u>	LOGIC BOARD, AC
2	<u>K1D8284-1CC</u> <u>K1D8424-1CC</u> <u>K1D8387-1CC</u>	MOTOR DRIVE BOARD, 1PH, SL585U, SL595U POWER BOARD, 3PH, SL585U, SL595U EXPANSION BOARD, UL325
4	<u>K77-36541</u>	ANTENNA
5	<u>K21-3260-1</u> <u>K204A0276</u>	TRANSFORMER, 120/208/230/460/60VA TRANSFORMER, 575VAC, 200VA
6	<u>K75-38037</u> <u>K180A0385-3</u>	LATCH COVER AND SWITCH, 1PH LATCH COVER AND SWITCH, 3PH
7	<u>K75-10177</u>	BRAKE HUB KIT
8	<u>K10-30702-2</u>	CHAIN GUARD TOP COVER
9	<u>K75-37700</u>	CHAIN GUARD AND IDLERS
10	<u>K305-153613</u>	IDLER SPROCKET
11	<u>K23-34815-1</u>	RESET SWITCH
12	<u>K10-30699-1</u>	CHAIN COVER MOUNTING BRACKET WITH COVER
13	<u>K32-10540</u>	GEAR REDUCER, 20:1
14	<u>K19-4853</u>	CHAIN, #48X53, NO ML
15	<u>K13-32087</u>	RPM CUP
16	<u>K13-10024</u>	LIMIT NUT
17	<u>K12-3601</u>	PILLOW BLOCK BEARING
18	<u>K11-37823</u>	IDLER SHAFT
19	<u>K94-37848-1</u> <u>K94-37849-1</u> <u>K94-37849-2</u> <u>K94-37850-1</u> <u>K94-37850-2</u> <u>K94-37848-2</u>	MOTOR, SL595101U MOTOR, SL595103U MOTOR, SL595203U MOTOR, SL595105U MOTOR, SL595205U MOTOR, SL595151U
ELECTRICAL BOX ASSEMBLY		
	<u>K74-39299-1</u>	E-BOX, SL595101U, SL595151U
	<u>K74-39299-2</u>	E-BOX, SL595103U, SL595203U
	<u>K74-39299-3</u>	E-BOX, SL595105U, SL595205U
NOT SHOWN IN DIAGRAM		
	<u>K77-38121</u>	WIRE HARNESS, SL585U, SL595U
	<u>K94-37871</u>	RESET SWITCH, WITH ID HARNESS, SL595
	<u>K94-37884</u>	ALARM KIT, SL595U
	<u>K94-38062-2</u>	POWER BOARD ID RESISTOR, 1HP, 3PH
	<u>K94-38062-3</u>	POWER BOARD ID RESISTOR, 2HP, 3PH
	<u>K94-38062-5</u>	POWER BOARD ID RESISTOR, 1HP, 575V
	<u>K94-38062-6</u>	POWER BOARD ID RESISTOR, 2HP, 575V
	<u>K77-37683</u>	MAIN BOARD STANDOFFS, QTY. 10
	<u>K77-38105</u>	C CLAMP KIT, SL595U, QTY. 2
	<u>K91-G0149</u>	IDLER BOLT
	<u>K15-50B18QGx</u>	OUTPUT SPROCKET
	<u>K10-3209</u>	GATE BRACKET KIT
	<u>K11-3503</u>	TAKE UP BOLT
	<u>K82-QN43-12</u>	SCREW, 7/16"-14X12
	<u>19-3025</u>	CHAIN, #50X471, NP
ACCESSORIES		
	<u>HTRNB</u>	HEATER KIT FOR AC PAD MOUNT GATE OPERATORS
	<u>HTR460</u>	HEATER KIT FOR AC PAD MOUNT GATE OPERATORS, 460V ONLY

SERVICE KITS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
K1	<u>K71-B1PH-1</u> <u>K71-B3PH-1</u> <u>K71-B3PH</u> <u>K71-B575</u>	BRAKE SOLENOID, 120/240V, SL585U/SL595U BRAKE SOLENOID, 240V, 3PH INTERNAL BRAKE SOLENOID, 208/230V, 3PH INTERNAL BRAKE SOLENOID, 575V
K2	<u>K75-37687</u>	ENCLOSURE
K3	<u>K75-37549</u>	DISCONNECT KIT
K4	<u>K76-37667-2</u>	LIMIT BOX KIT
K5	<u>K75-37556</u>	DRIVE SHAFT KIT
K6	<u>K75-32463</u>	CLUTCH KIT
NOT SHOWN IN DIAGRAM		
	<u>K39-10541</u>	CLUTCH DISK

NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com