


HDSW24UL

REPLACEMENT PARTS ——— KEY ITEMS + DIAGRAM



NOT SHOWN	
K41-0047-000	Wire Harness Kit, HD Gates
K41-0123-000	Power Switches and Wire Harness, HD
K94-34778	Wire Harness - control board to expansion board
K41-0102-000	Battery Harness, 33AH, HD Gates
40-39235	Warning Sign

HDSW24UL

REPLACEMENT PARTS ————— KEY ITEMS + PARTS LIST

KEY#	PART#	DESCRIPTION
1	<u>K41-0086-000</u>	OUTPUT SHAFT ASSEMBLY, HDSW24UL
2	<u>K41-0085-000</u>	CLUDGE ASSEMBLY, HDSW24UL
3	<u>K09-50119</u>	OUTPUT ARM, Q059
4	<u>K41-0138-000</u>	STANDARD ARM, HDSW24UL
5	<u>29-NP712</u>	BATTERY, 12V, 7AH
6	<u>K74-30762</u>	BATTERY PACK, 12V, 7A, QTY. 2
7	<u>K41-0092-000</u>	APS ENCODER, HDSW24UL
8	<u>K41-0083-000</u>	BRIDGE RECTIFIER, HD GATES
9	<u>K41-0075-000</u>	DUST GUARD, HD SLIDE
10	<u>K41-0073-000</u>	HD MAIN CONTROL BOARD
11	<u>K41-0071-000</u>	HD POWER BOARD
12	<u>K41-0082-000</u>	HD MOTOR
13	<u>K41-0095-000</u>	MOTOR DRIVE, HD GATES
14	<u>K41-0067-000</u>	TRANSFORMER, HD SWING AND SLIDE
15	<u>K41-0066-000</u>	GEAR REDUCER, 1600:1, HDSW24UL
16	<u>K41-0072-000</u>	RELAY ADAPTER BOARD, HD
17	<u>K1D8387-1CC</u>	EXPANSION BOARD, UL325
18	<u>K41-0074-000</u>	CONTROL BOARD, PIVOT BRACKET AND SLIDE
19	<u>K41-0078-000</u>	EMI BOARD WITH COVER KIT, HD GATES
20	<u>K1D7078</u>	EMI BOARD
21	<u>K41-0090-000</u>	COVER, HDSW24UL
22	<u>K13-36117-1</u>	CLUDGE COVER
23	<u>K75-36260</u>	LOCK AND KEYS
24	<u>K41-0124-000</u>	ANTENNA AND CONNECTING WIRE, HD
NOT SHOWN IN DIAGRAM		
	<u>K41-0047-000</u>	WIRE HARNESS KIT, HD GATES
	<u>K41-0050-000</u>	RESET WITH ID RESISTOR, HDSW24UL
	<u>K41-0123-000</u>	POWER SWITCHES AND WIRE HARNESS, HD
	<u>K94-34778</u>	BOARD TO BOARD WIRE HARNESS, 24V
	<u>K41-0105-000</u>	BATTERY TRAY, 33AH, HD

NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit Partner.LiftMaster.com