



GARAGE DOOR OPENER — REPAIR + SERVICE PARTS



KEY#	PART#	DESCRIPTION
1A	K031D0380M	SPROCKET COVER
2A	041C4220A	CHAIN DRIVE GEAR AND SPROCKET KIT
3	041A2817	DRIVE GEAR AND WORM KIT
4	041B4245-1	AC POWER CORD, 6'
5	143D150	END PANEL
6	K143D0100-1	END PANEL
7	041C0279	LIGHT SOCKET KIT
8	K108D0034	LIGHT LENS
9	K030B0532-1	CAPACITOR, 56UF, 220V
10	K012A0373	CAPACITOR BRACKET
11	041A3150	TERMINAL BLOCK KIT
12	041D3058	MOTOR AND BRACKET KIT
13	041A3583-3	COVER, 1260
	041A3583-11	COVER, 1265
14	041A2818	LIMIT SWITCH DRIVE GEAR KIT
15	041D3452	LIMIT SWITCH KIT
16	041C4398A	RPM SENSOR KIT
17	041C4246	WIRE HARNESS KIT
18	041A2826	SHAFT BEARING KIT
19	041A2822A	INTERRUPTER CUP
20	041A5021-I	RECEIVER LOGIC BOARD, 390MHZ, 1265
21	041A4888	END PANEL
	NOT SHOWN IN DIAGRAM	
	041A2825	HARDWARE KIT


INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	004A1008	CHAIN, #48, WITH ML
2	041A4813	CHAIN PULLEY BRACKET
3	041A3489	TROLLEY KIT, T-RAIL
4	G1707	T-TRAIL ASSEMBLY FULL CHAIN, 7'
	G1708	T-TRAIL ASSEMBLY FULL CHAIN, 8'
	G1710	T-TRAIL ASSEMBLY FULL CHAIN, 10'
5	041D3484	CHAIN KIT, 7'
	041D3483	CHAIN KIT, 8'
	041D3485	CHAIN KIT, 10'
6	K083A0011-1	LITHIUM RAIL GREASE



RAIL INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	041A5273-1	WALL-MOUNTED DOOR CONTROL PANEL
2	83LM	3 BUTTON REMOTE CONTROL
3	K010A0020	3V CR2032 LITHIUM BATTERY
4	K029B0137	REMOTE CONTROL VISOR CLIP
5	041A2828	EMERGENCY MANUAL RELEASE ROPE
6	041B4494-1	WHITE/RED BELL WIRE
7	041A4353	HEADER BRACKET
8	041A5047-1	DOOR BRACKET
9	041-0136	SAFETY SENSOR KIT
10	4178B0034B	STRAIGHT DOOR ARM
11	041B0035B	CURVED DOOR ARM
12	041-0155-000	SAFETY SENSOR BRACKET KIT
	NOT SHOWN IN DIAGRAM	
	041A2770-17	HARDWARE KIT
	K012B0776	HANGING BRACKET KIT



NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit partner.liftmaster.com