


# 1270, 1280, 1280R


**GARAGE DOOR OPENER — REPAIR + SERVICE PARTS**



KEY#	PART#	DESCRIPTION
1	<a href="#">041A4371</a>	BELT CAP RETAINER
2	<a href="#">041A4885-2</a>	BELT DRIVE GEAR AND SPROCKET KIT
3	<a href="#">041A2817</a>	DRIVE GEAR AND WORM KIT
4	<a href="#">041B4245-1</a>	AC POWER CORD, 6'
5	<a href="#">041C4876</a>	WIRE HARNESS KIT
6	<a href="#">041A4252-6G</a>	RECEIVER LOGIC BOARD, 390MHZ
	<a href="#">041A5021-5I</a>	RECEIVER LOGIC BOARD, 390MHZ, 1280R
7	<a href="#">041A3673-1</a>	END PANEL
8	<a href="#">041C0279</a>	LIGHT SOCKET KIT
9	<a href="#">K108D0034</a>	LIGHT LENS
10	<a href="#">K030B0532-1</a>	CAPACITOR, 56UF, 220V
11	<a href="#">K012A0373</a>	CAPACITOR BRACKET
12	<a href="#">041A3150</a>	TERMINAL BLOCK KIT
13	<a href="#">041C4842</a>	MOTOR AND BRACKET KIT
14	<a href="#">041A3583-7</a>	COVER
15	<a href="#">041A2818</a>	LIMIT SWITCH DRIVE GEAR KIT
16	<a href="#">041D3452</a>	LIMIT SWITCH KIT
17	<a href="#">041C4398A</a>	RPM SENSOR KIT
18	<a href="#">041A2826</a>	SHAFT BEARING KIT
19	<a href="#">041A2822A</a>	INTERRUPTER CUP
20	<a href="#">041A4416</a>	END PANEL


**INSTALLATION — ASSEMBLY + SERVICE PARTS**

KEY#	PART#	DESCRIPTION
1	<a href="#">004A1008</a>	CHAIN, #48, WITH ML
2	<a href="#">041A3588-1</a>	BELT PULLEY BRACKET KIT
3	<a href="#">041B3869-3A</a>	BELT DRIVE TROLLEY KIT
4	<a href="#">K109B0033</a>	LINK CONNECTOR
5	<a href="#">4183B099</a>	ONE-PIECE T-RAIL
6	<a href="#">041A3589-3</a>	BELT KIT, 7'
	<a href="#">041A3589-1</a>	BELT KIT, 8'
	<a href="#">041A3589-2</a>	BELT KIT, 10'
7	<a href="#">041B4103</a>	BELT TENSIONER KIT
	<b>NOT SHOWN IN DIAGRAM</b>	
	<a href="#">K083A0011-1</a>	LITHIUM RAIL GREASE
	<a href="#">041A6689</a>	THREADED SHAFT, D SHAPE



**RAIL INSTALLATION — ASSEMBLY + SERVICE PARTS**

KEY#	PART#	DESCRIPTION
1	<a href="#">041A4202-6B</a>	WALL-MOUNTED DOOR CONTROL PANEL
2	<a href="#">K010A0014</a>	BATTERY, 12V
3	<a href="#">K029C0151</a>	REMOTE CONTROL VISOR CLIP
4	<a href="#">041A3984-7</a>	REMOTE CONTROL
5	<a href="#">041A2828</a>	EMERGENCY MANUAL RELEASE ROPE
6	<a href="#">041B4494-1</a>	WHITE/RED BELL WIRE
7	<a href="#">041A5047-4</a>	DOOR BRACKET
8	<a href="#">041A4353-1</a>	HEADER BRACKET
9	<a href="#">041-0136</a>	SAFETY SENSOR KIT
10	<a href="#">041-0155-000</a>	SAFETY SENSOR BRACKET KIT
11	<a href="#">041A5281-1</a>	SAFETY SENSOR EXTENSION BRACKET KIT
12	<a href="#">041B0035B</a>	CURVED DOOR ARM
	<a href="#">4178B0034B</a>	STRAIGHT DOOR ARM
	<b>NOT SHOWN IN DIAGRAM</b>	
	<a href="#">041A2770-17</a>	HARDWARE KIT
	<a href="#">K012B0776</a>	HANGING BRACKET KIT



**NOTE:** Part numbers that are not highlighted are **no longer available**.

**TIME TO UPGRADE?** Visit [partner.liftmaster.com](http://partner.liftmaster.com)