


# 3800, 3800P, 3800PLD


GARAGE DOOR OPENER — REPAIR + SERVICE PARTS



KEY#	PART#	DESCRIPTION
1	<a href="#">041DJ001B</a>	RECEIVER LOGIC BOARD, 315MHZ
2	<a href="#">041B8861</a>	TRAVEL MODULE WITH WIRE HARNESS
	<a href="#">041A6118</a>	TRAVEL MODULE WITH WIRE HARNESS 3800
3	<a href="#">041C0168</a>	TRANSFORMER, 120V
4	<a href="#">041A6095</a>	MOTOR REPLACEMENT KIT
5	<a href="#">041B0122</a>	AC POWER CORD KIT, RJO
6	<a href="#">041A6348-3</a>	COVER, RJO
<b>NOT SHOWN IN DIAGRAM</b>		
	<a href="#">041DJ001B-390</a>	RECEIVER LOGIC BOARD, 390MHZ

INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	<a href="#">398LM</a>	LCD MOTOION DETECTING DOOR CONTROL
2	<a href="#">373LM</a>	SECURITY+ 3-BUTTON REMOTE CONTROL - 315MHZ
3	<a href="#">K010A0020</a>	BATTERY, 3V, CR2032
4	<a href="#">K029B0137</a>	REMOTE CONTROL VISOR CLIP
5	<a href="#">041A4582</a>	ROPE AND HANDLE KIT, RJO
6	<a href="#">041B4494-1</a>	BELL WIRE KIT
7	<a href="#">041A6104</a>	CABLE TENSION MONITOR KIT
8	<a href="#">041B6228</a>	MOUNTING BRACKET KIT, RJO
9	<a href="#">041-0136</a>	SAFETY SENSOR KIT
10	<a href="#">041D8615</a>	DOOR SHAFT COLLAR, RJO
11	<a href="#">041A6102</a>	POWER DOOR LOCK KIT
12	<a href="#">041-0155-000</a>	SAFETY SENSOR BRACKET KIT
13	<a href="#">380LM</a>	WALL/CEILING MOUNT REMOTE LIGHT
14	<a href="#">041D0096-1</a>	LIGHT LENS
<b>NOT SHOWN IN DIAGRAM</b>		
	<a href="#">480LM</a>	RJO 3800 ALTERNATE MOUNTING/EXTENSION KIT
	<a href="#">041A5281-1</a>	SAFETY SENSOR EXTENSION BRACKET KIT
	<a href="#">041A6288</a>	WORK LIGHT HARDWARE KIT
	<a href="#">041A6298</a>	INSTALLATION HARDWARE KIT



**NOTE:** Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit [partner.liftmaster.com](http://partner.liftmaster.com)