


3850, 3850-267


GARAGE DOOR OPENER — REPAIR + SERVICE PARTS



KEY#	PART#	DESCRIPTION
1	041C0076	BELT SPROCKET COVER KIT
2	041B4245-1	AC POWER CORD, 6'
3	041B4375-3	TERMINAL BLOCK, NO MOV
4	041A6281	WIRE HARNESS KIT
5	041D0794	MOTOR WITH POSITIONING SENSOR
6	041DB002-2	RECEIVER LOGIC BOARD, 315MHZ
7	041A6231	BATTERY DOOR REPLACEMENT KIT
8	041C0190	TRANSFORMER AND WIRE HARNESS KIT
9	041D0504-4	COVER
10	K108D0079M	LIGHT LENS
11	041C0279	LIGHT SOCKET KIT
NOT SHOWN IN DIAGRAM		
	485LM	BATTERY BACKUP KIT, 12V
	041DB002-2-390	RECEIVER LOGIC BOARD, 390MHZ
	041A5624-8	PASSPOINT KIT


INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	004A1008	CHAIN, #48, WITH ML
2	041B5424	BELT PULLEY BRACKET KIT
3	041B3869-3A	BELT DRIVE TROLLEY KIT
4	K109B0033	LINK CONNECTOR
5	G2777	BELT DRIVE RAIL ASSEMBLY, 1 PC, 7'
	G2778	BELT DRIVE RAIL ASSEMBLY, 1 PC, 8'
	G2770	BELT DRIVE RAIL ASSEMBLY, 1 PC, 10'
6	041A5434-11A	BELT KIT, 7'
	041A5434-13A	BELT KIT, 8'
	041A5434-14A	BELT KIT, 10'
7	041B4103	BELT TENSIONER KIT
NOT SHOWN IN DIAGRAM		
	K083A0011-1	LITHIUM RAIL GREASE
	041A6689	THREADED SHAFT, D SHAPE



RAIL INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	398LM	DOOR CONTROL
2	373P	3-BUTTON REMOTE CONTROL
3	K010A0019	BATTERY, 3V
	K010A0056	BATTERY, 3V, CR2450
4	K029C0151	REMOTE CONTROL VISOR CLIP
5	041A2828	EMERGENCY MANUAL RELEASE ROPE
6	041B4494-1	WHITE/RED BELL WIRE
7	041A5047	DOOR BRACKET
8	041A4353	HEADER BRACKET
9	041-0136	SAFETY SENSOR KIT
10	4178B0034B	STRAIGHT DOOR ARM
11	041B0035B	CURVED DOOR ARM
12	041-0155-000	SAFETY SENSOR BRACKET KIT
13	041A5281-1	SAFETY SENSOR EXTENSION BRACKET KIT



NOTE: Part numbers that are not highlighted are no longer available.

TIME TO UPGRADE? Visit partner.liftmaster.com