


BELT DRIVE

8155, 8155W



POWERED BY myQ.


GARAGE DOOR OPENER — REPAIR + SERVICE PARTS



KEY#	PART#	DESCRIPTION
1	041A4371	BELT CAP RETAINER
2	041A4885-4	BELT DRIVE GEAR AND SPROCKET KIT
3	041A2817	DRIVE GEAR AND WORM KIT
4	041A5484	END PANEL, 8155
	041A8393	END PANEL, 8155W
5	041C0279	LIGHT SOCKET KIT
6	K108D0079M	LIGHT LENS
7	K030B0532-1	CAPACITOR, 56UF, 220V
8	K012A0373	CAPACITOR BRACKET
9	041D7440	MOTOR, 1/2HP WITH TRAVEL MODULE
10	041D7742-7	TRAVEL MODULE
11	041D8140	COVER, 8155
	041D9018	COVER, 8155W
12	045ACTMC	RECEIVER LOGIC BOARD, 2.0
	050ACTB	RECEIVER LOGIC BOARD
	050ACTBMC	RECEIVER LOGIC BOARD
	050ACTWFMC	RECEIVER LOGIC BOARD, AC, WI-FI
13	041D0239	END PANEL, 8155
	041D0239-1	END PANEL, 8155W
14	041B4245-1	AC POWER CORD, 6'
	NOT SHOWN IN DIAGRAM	
	041A7946	WIRE HARNESS
	041A3150	TERMINAL BLOCK


INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	004A1008	CHAIN, #48, WITH ML
2	041B5424	BELT PULLEY BRACKET KIT
3	041B3869-3A	BELT DRIVE TROLLEY KIT
4	G2777	BELT DRIVE RAIL ASSEMBLY, 1 PC, 7'
	G2778	BELT DRIVE RAIL ASSEMBLY, 1 PC, 8'
	G2770	BELT DRIVE RAIL ASSEMBLY, 1 PC, 10'
5	041A5434-11A	BELT KIT, 7'
	041A5434-13A	BELT KIT, 8'
	041A5434-14A	BELT KIT, 10'
	NOT SHOWN IN DIAGRAM	
	041B4103	BELT TENSIONER KIT
	041A6689	THREADED SHAFT, D SHAPE
	K083A0011-1	LITHIUM RAIL GREASE



RAIL INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	K010A0020	3V CR2032 LITHIUM BATTERY
2	K029B0137	REMOTE CONTROL VISOR CLIP
3	041A2828	EMERGENCY MANUAL RELEASE ROPE
4	041B4494-1	WHITE/RED BELL WIRE
5	041A5047	DOOR BRACKET
6	041A4353	HEADER BRACKET
7	041-0136	SAFETY SENSOR KIT
8	4178B0034B	STRAIGHT DOOR ARM
9	041B0035B	CURVED DOOR ARM
10	041-0155-000	SAFETY SENSOR BRACKET KIT
	NOT SHOWN IN DIAGRAM	
	041A2770-17	HARDWARE KIT
	041A5281-1	SAFETY SENSOR EXTENSION BRACKET KIT
	K012B0776	HANGING BRACKET KIT



NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit partner.liftmaster.com