


8165, 8165W


GARAGE DOOR OPENER — REPAIR + SERVICE PARTS



KEY#	PART#	DESCRIPTION
1	K031D0380M	SPROCKET COVER
2	041C4220A	CHAIN DRIVE GEAR AND SPROCKET KIT
3	041A2817	DRIVE GEAR AND WORM KIT
4	041A5484	END PANEL
	041A8393	END PANEL, 8165W
5	041C0279	LIGHT SOCKET KIT
6	K108D0079M	LIGHT LENS
7	K030B0532-1	CAPACITOR, 56UF, 220V
8	K012A0373	CAPACITOR BRACKET
9	041D7440	MOTOR WITH TRAVEL MODULE, 1/2HP
10	041D7742-7	TRAVEL MODULE, 1/2HP
11	041D8140	COVER, 8165
	041D9018	COVER, 8165W
12	045ACTMC	RECEIVER LOGIC BOARD, 2.0
	050ACTWPMC	RECEIVER LOGIC BOARD, AC, WI-FI
13	041D0239	END PANEL, 8165
	041D0239-1	END PANEL, 8165W
NOT SHOWN IN DIAGRAM		
	041B4245-1	AC POWER CORD, 6'
	041A3150	TERMINAL BLOCK
	041A7946	WIRE HARNESS


INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	004A1008	CHAIN, #48, WITH ML
2	041A4813	CHAIN PULLEY BRACKET
3	041A3489	TROLLEY ASSEMBLY
4	G1707	T-TRAIL ASSEMBLY FULL CHAIN, 7'
	G1708	T-TRAIL ASSEMBLY FULL CHAIN, 8'
	G1710	T-TRAIL ASSEMBLY FULL CHAIN, 10'
5	041D3484	CHAIN KIT, 7'
	041D3483	CHAIN KIT, 8'
	041D3485	CHAIN KIT, 10'
NOT SHOWN IN DIAGRAM		
	K083A0011-1	LITHIUM RAIL GREASE



RAIL INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	K029B0137	REMOTE CONTROL VISOR CLIP
2	041A2828	EMERGENCY MANUAL RELEASE ROPE
3	041A5047	DOOR BRACKET
4	041A4353	HEADER BRACKET
5	041-0136	SAFETY SENSOR KIT
6	041B0035B	CURVED DOOR ARM
7	4178B0034B	STRAIGHT DOOR ARM
8	041-0155-000	SAFETY SENSOR BRACKET KIT
9	041B4494-1	WHITE/RED BELL WIRE
NOT SHOWN IN DIAGRAM		
	041A2770-17	HARDWARE KIT
	K012B0776	HANGING BRACKET KIT
	041A5281-1	SAFETY SENSOR EXTENSION BRACKET KIT



NOTE: Part numbers that are not highlighted are no longer available.

TIME TO UPGRADE? Visit partner.liftmaster.com