



GARAGE DOOR OPENER — REPAIR + SERVICE PARTS



KEY#	PART#	DESCRIPTION
1	041C0589-2	BELT CAP RETAINER KIT
2	041A7618	END PANEL WITH BATTERY COVER
3	041A7562	LIGHT LENS
4	041C0279	LIGHT SOCKET KIT
5	041D0277-1	TRANSFORMER, WI-FI BATTERY BACKUP
6	041-0037	COVER, 85503, 85503-267
7	041-0236-000	MOTOR WITH TRAVEL MODULE, DC
8	041D8071-4	TRAVEL MODULE KIT, UNIVERSAL DC
9	041D0216-2	END PANEL
10	050DCTBMC	RECEIVER LOGIC BOARD, DC, WI-FI
11	485LM	BACKUP BATTERY, 12V
12	041-0101	DECORATIVE COVER
13	041-0041	CAMERA WITH DECORATIVE COVER
NOT SHOWN IN DIAGRAM		
	041B4245-1	AC POWER CORD, 6'
	041A3150	TERMINAL BLOCK
	041D9204	WIRE HARNESS, LED


INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	041A5434-11A	BELT KIT, 7'
	041A5434-13A	BELT KIT, 8'
	041A5434-14A	BELT KIT, 10'
2	041B5424	BELT PULLEY BRACKET KIT
3	004A1008	CHAIN, #48, MASTER LINK
4	G2777	BELT DRIVE RAIL ASSEMBLY, 1 PC, 7'
	G2778	BELT DRIVE RAIL ASSEMBLY, 1 PC, 8'
	G2770	BELT DRIVE RAIL ASSEMBLY, 1 PC, 10'
5	041B3869-3A	BELT DRIVE TROLLEY KIT
6	041A6689	THREADED SHAFT, D SHAPE
7	041B4103	BELT TENSIONER KIT
NOT SHOWN IN DIAGRAM		
	K083A0011-1	LITHIUM RAIL GREASE



RAIL INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	041B0035B	CURVED DOOR ARM
2	041A5047-1	DOOR BRACKET
3	041A2828	EMERGENCY MANUAL RELEASE ROPE
4	041A4353-1	HEADER BRACKET
5	K029B0137	REMOTE CONTROL VISOR CLIP
6	041-0155-000	SAFETY SENSOR BRACKET KIT
7	041-0136	SAFETY SENSOR KIT
8	4178B0034B	STRAIGHT DOOR ARM
9	041B4494-1	WHITE/RED BELL WIRE
10	K010A0020	3V CR2032 LITHIUM BATTERY
NOT SHOWN IN DIAGRAM		
	041A5281-1	SAFETY SENSOR EXTENSION BRACKET KIT
	485LM	BACKUP BATTERY, 12V
	K012B0776	HANGING BRACKET KIT
	041A7920-2	HARDWARE KIT



NOTE: Part numbers that are not highlighted are **no longer available**.

TIME TO UPGRADE? Visit partner.liftmaster.com