


8557, 8557W


GARAGE DOOR OPENER — REPAIR + SERVICE PARTS



KEY#	PART#	DESCRIPTION
1	041A4371	BELT CAP RETAINER
2	041A4885-5	BELT DRIVE GEAR AND SPROCKET KIT
3	041A2817	DRIVE GEAR AND WORM KIT
4	041A7756	END PANEL, 8557
	041A7756-1	END PANEL, 8557W
5	041C0279	LIGHT SOCKET KIT
6	041A7562	LIGHT LENS
7	K030B0652-1	CAPACITOR, 89UF, 120V
8	041A5532	GEAR CASE KIT
9	041A7767	MOTOR, 3/4HP WITH TRAVEL MODULE
10	041D7742-5	TRAVEL MODULE, 3/4HP
11	041A7619-4	COVER, 8557
	041D8258	COVER, 8557W
12	045ACTMC	RECEIVER LOGIC BOARD, 2.0
	050ACTWFMC	RECEIVER LOGIC BOARD, AC, WI-FI
13	041D0216	END PANEL, 8557
	041D8198	END PANEL, 8557W


INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	041A5434-11A	BELT KIT, 7'
	041A5434-13A	BELT KIT, 8'
	041A5434-14A	BELT KIT, 10'
2	041B5424	BELT PULLEY BRACKET KIT
3	004A1008	CHAIN, #48, MASTER LINK
4	G2777	BELT DRIVE RAIL ASSEMBLY, 1 PC, 7'
	G2778	BELT DRIVE RAIL ASSEMBLY, 1 PC, 8'
	G2770	BELT DRIVE RAIL ASSEMBLY, 1 PC, 10'
5	041B3869-3A	BELT DRIVE TROLLEY KIT
6	041A6689	THREADED SHAFT, D SHAPE
7	041B4103	BELT TENSIONER KIT
	NOT SHOWN IN DIAGRAM	
	K083A0011-1	LITHIUM RAIL GREASE



RAIL INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	041B0035B	CURVED DOOR ARM
2	041A5047-1	DOOR BRACKET
3	041A2828	EMERGENCY MANUAL RELEASE ROPE
4	041A4353-1	HEADER BRACKET
5	K029B0137	REMOTE CONTROL VISOR CLIP
6	041-0155-000	SAFETY SENSOR BRACKET KIT
7	041-0136	SAFETY SENSOR KIT
8	4178B0034B	STRAIGHT DOOR ARM
9	041B4494-1	WHITE/RED BELL WIRE
10	K010A0020	3V CR2032 LITHIUM BATTERY
	NOT SHOWN IN DIAGRAM	
	485LM	BACKUP BATTERY, 12V
	K012B0776	HANGING BRACKET KIT
	041A7920-2	HARDWARE KIT



NOTE: Part numbers that are not highlighted are no longer available.

TIME TO UPGRADE? Visit partner.liftmaster.com