


8587, 8587W, 8587WL


GARAGE DOOR OPENER — REPAIR + SERVICE PARTS



KEY#	PART#	DESCRIPTION
1	041C5069	RAIL SUPPORT BRACKET KIT
2	041A4208-2	CHAIN SPREADER KIT
3	041A5658-1	DUAL GEAR AND SPROCKET KIT
4	041A2817	DRIVE GEAR AND WORM KIT
5	041A5532	GEAR CASE KIT
6	041B4245-1	AC POWER CORD, 6'
7	041A7756-1	END PANEL
8	041C0279	LIGHT SOCKET KIT
9	041A7562	LIGHT LENS
10	K030B0652-1	CAPACITOR, 89UF, 120V
11	041A3150	TERMINAL BLOCK KIT
12	041A7767	MOTOR, 3/4HP WITH TRAVEL MODULE
13	041D7742-5	TRAVEL MODULE, 3/4HP
14	041A7619-4	COVER, 8587
	041D8258	COVER, 8587W
	041D8856	COVER, 8587WL
15	045ACTMC	RECEIVER LOGIC BOARD, 2.0
	050ACTWFMC	RECEIVER LOGIC BOARD, AC, WI-FI, NO LOCK
	050ACTWFLKMC	RECEIVER LOGIC BOARD, AC, WI-FI, LOCK
16	041D0216	END PANEL
	041D8198	END PANEL
	041D0216-2	END PANEL, LOCK
	NOT SHOWN IN DIAGRAM	
	041A7814	WIRE HARNESS KIT, DUAL LIGHT


INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	041D3484	CHAIN KIT, 7'
	041D3483	CHAIN KIT, 8'
	041D3485	CHAIN KIT, 10'
2	041A2780	CHAIN PULLEY BRACKET
3	004A1008	CHAIN, #48, WITH ML
4	G3707CH	CHAIN DRIVE RAIL ASSEMBLY, 1PC, 7'
	G3708CH	CHAIN DRIVE RAIL ASSEMBLY, 1PC, 8'
	G3710CH	CHAIN DRIVE RAIL ASSEMBLY, 1PC, 10'
5	041A3489	TROLLEY ASSEMBLY
6	041A6689	THREADED SHAFT, D SHAPE
	NOT SHOWN IN DIAGRAM	
	K083A0011-1	LITHIUM RAIL GREASE



RAIL INSTALLATION — ASSEMBLY + SERVICE PARTS

KEY#	PART#	DESCRIPTION
1	041B0035B	CURVED DOOR ARM
2	041A5047-1	DOOR BRACKET
3	041A2828	EMERGENCY MANUAL RELEASE ROPE
4	041A4353-1	HEADER BRACKET
5	K029C0151	REMOTE CONTROL VISOR CLIP
6	041-0155-000	SAFETY SENSOR BRACKET KIT
7	041-0136	SAFETY SENSOR KIT
8	4178B0034B	STRAIGHT DOOR ARM
9	041B4494-1	WHITE/RED BELL WIRE
10	K010A0020	3V CR2032 LITHIUM BATTERY
11	041A5281-1	SAFETY SENSOR EXTENSION BRACKET KIT
	NOT SHOWN IN DIAGRAM	
	041A2770-17	HARDWARE KIT
	K012B0776	HANGING BRACKET KIT



NOTE: Part numbers that are not highlighted are no longer available.

TIME TO UPGRADE? Visit partner.liftmaster.com